


PCN #:	2009002A	PCN ISSUE DATE:	July 24, 2009
PCN TITLE: Discontinuation Notice for Firefly MV Board-Level IEEE 1394a Models with M12 Microlens Mount			
REVISION:	1.0	CUSTOMER CONTACT:	sales@ptgrey.com
TYPE OF CHANGE:			
<input type="checkbox"/> Electrical Specification <input type="checkbox"/> Mechanical Specification <input type="checkbox"/> Firmware Specification <input type="checkbox"/> Regulatory or Compliance		<input type="checkbox"/> Part Number <input type="checkbox"/> Selling Price or Structure <input checked="" type="checkbox"/> DISC (Discontinued)	
LAST-TIME BUY DATE: Purchase orders for the Affected Part Numbers will not be accepted after August 24, 2009 .			
LAST-TIME SHIP DATE: The Affected Part Numbers will be discontinued and no further units shipped after November 24, 2009 .			
AFFECTED PART NUMBER(S): FFMV-03MTM-60 FFMV-03MTC-60			
CHANGE DESCRIPTION: The Affected Part Numbers will be discontinued according to the dates outlined above. New "97" Point Grey part numbers will be created to allow qualified customers and OEM's to purchase the board-level product with M12 microlens holder. This does not affect accessory (p/n ACC-xx) part numbers for the microlens holder or individual microlenses. Customers are encouraged to contact Sales to discuss ordering options.			
REASON FOR CHANGE			
<ul style="list-style-type: none"> Minimize the risk of damage to camera components due to absence of protective case enclosure. 			
ANTICIPATED IMPACT ON FIT / FORM / FUNCTION / RELIABILITY			
<ul style="list-style-type: none"> Customers who require a board-level form factor with microlens holder upon delivery, who are unable to order the new "97" part number, and who do not want to void the Hardware Warranty by removing the CS lens mount and camera PCB from the FFMV-03MT-CS enclosure may be impacted by this change. Customers are encouraged to contact Sales to discuss ordering options. 			
REFERENCE DOCUMENTS			
<ul style="list-style-type: none"> PCN2009001A: Discontinuation Notice for Firefly MV Board-Level IEEE 1394a Models with CS 			

Document Number:	PCN2009002A
Revision Number:	1.0
Revision Date:	23-Jul-09
Document Availability:	Public Distribution

Document Number:	PCN2009002A
Revision Number:	1.0
Revision Date:	23-Jul-09
Document Availability:	Public Distribution

[Lens Mount](#)

- [PCN2009003A: Discontinuation Notice for Firefly MV IEEE 1394a Development Accessory Kit](#)
- [Point Grey Firefly MV Hardware Warranty](#)

FREQUENTLY ASKED QUESTIONS

- *I need a board-level camera with microlens holder for my application. What do I do?*
[Contact Sales](#) to determine if you meet the requirements necessary to purchase the new “97” part number that Point Grey has created to allow qualified customers and OEM’s to purchase the board-level product with M12 microlens holder.
- *I am unable to purchase the special part number described above. What options do I have?*
Point Grey will continue to make microlens-related accessories, such as M12 lens holders and lenses, available as separate ACC-xx part numbers (p/n ACC-xx). Customers can also use a CS to M12 lens adapter—or C to M12 adapter by using the 5 mm C-mount adapter included with the camera—to install a microlens in the CS lens holder used by the FFMV-03MT-CS. Note that some short focal length (wide angle) microlenses may collide with the protective glass within the CS lens holder housing while focusing to infinity.
- *I want to mount a microlens holder and lens to the FFMV-03MT-CS. Does removing the camera PCB from the plastic case and removing the CS lens holder void the warranty?*
Yes, removing the printed circuit board from the protective case enclosure voids the Hardware Warranty. Customers may elect to use the C/CS to M12 lens adapter solution discussed above.



Figure 1: FFMV-03MT-CS with CS to M12 lens adapter